

## Vela Electric - Reset Thermostat

These items are fully tested prior to leaving the manufacturer. Therefore, before you begin the process of connecting your heater to via Bluetooth or WiFi, you first need to perform a reset of the unit to ensure any previous manufacturer WiFi settings have been removed.

To do this, press and hold the WiFi button **(a)** on the thermostat control for **15 seconds**.



The thermostat control is located at the bottom of the heater. The unit will beep once followed by a series of flashing blue lights (see below).



The unit will then beep 5 times followed by a further sequence of flashing lights. Then after approximately 30 seconds the unit will beep a further 5 times and both lights will be steady. The unit will then beep a further 5 times and a green light will display to indicate the reset is complete (see below).

